Growatt | Different WiFi module type from Growatt

Marketing Department

WiFi module difference

Difference	Wi-Fi-E (1)	Wi-Fi-E (2)	Wi-Fi-S
SN Begin	4Kxxxxxxxx	IUBxxxxxxx	SARHxxxxx
LED	1 LED	3 LEDs (red, green, blue)	3LEDs (red, green, blue)
How to configurate	Configure via ShinePhone APP only	Configure via ShinePhone APP only	Configure via ShinePhone APP / WiFi module build in server
New and old replacement	Stop production in Sep. 2017	Start Sep. 2017	Sample testing state Will take place of previous version in 2019

Note: For more details information, please refer to the rated quick installation guide



Powering Tomorrow

Make the installer better understand where is the communication state:

Red LED flash — Inverter and WiFi module communication is OK

Green LED flash — Inverter, WiFi module and Router communication is OK

Blue LED flash — Communication succeed built

inverter, WiFi, router and Growatt server communication is OK



For troubleshooting

a. Configure WiFi module with the router information, when failed with ShinePhone APP

WiFi Mode	Auto O Manual
WiFi List	360WiFi-52A67D Search
WiFi Name Input	360WiFi-52A67D
WiFi Password	a12345678

b. Check WiFi module build in server setting parameter, set inverter time, etc.

For fix IP setting

You can turn off DHCP, and set the static IP address to WiFi module

DHCP		• ON (OFF		
IP Address		192.168.5	5.1		
Default Gateway		192.168.5	5.1		
Subnet Mask		255.255.2	255.0		
Default Domain		• ON	● ON ● OFF		
Server Domain		server.gro	watt.com	Domain Connect	
Server IP				IP Connect	
Server Port		5279			
Interval Time		5		(Min)	
Inverter Time		2017-08-3	30 14:31:21	Sync Time	
Dataloggter Time		2017-08-3	30 14:30:41	Sync Time	
	An	ply	Can	aal	



Powering Tomorrow